



Parts List		
Item	Qty	Description
1	2	Spherical Bearing Assembly
2	2	13mm Spacer, 11-SS-0009
3	6	6mm Spacer, 11-SS-0008
4	4	M10x1.25 Flanged Nut
5	2	M10x1.25 x 60mm Flanged Bolt JIS
6	2	M10x1.25 x 50mm Flanged Bolt JIS

- Before removing any factory end links, note the orientation and positioning of each end link.
- Adjust both spherical end link assembly lengths to ~70mm from Center-to-Center of the bearings.
 - Keep male and female rod ends perpendicular with one another as shown in the illustration.
- Tighten Jam Nuts on each end link assembly to ~35 ft·lb.
- Assemble the spherical end links onto the car, in their corresponding side, as shown in the diagram.
 - Sway Bar End will sit between Spacer (2) and Flanged Nut (4).
- Fasten the M10 Flanged Hardware (4,5,6) by applying a drop of the optional thread locker and tightening to a final torque of 40~45 ft·lb.
- *After roughly 100 road miles or day at the track, check hardware making sure everything is securely fastened. Also, wipe off any excess oils and spray a dry lubricant onto the bearings [such as Graphite or PTFE].*